



## Assembly Instructions for Man Made Timber (MmT) Noticeboards

### WALL MOUNTED

- Drill out the partly drilled counter-sunk holes 4no [single and 2 Bay] or 6no [3 bay] 6mm. (15/64") as per drawing. Exact positions may be varied to suit surface to be mounted to (but not nearer to the edge of the each bay).
- Fasten the board to the wall using screws and wall plugs supplied.

### FREESTANDING

#### Single Post

**For board P3A4 only**

- Drill 2 no counter-sunk holes 6mm (15/64") as per drawing.
- Drill 3.5mm (9/64") pilot holes in the post and fasten the board to the post using screws supplied.
- Concrete the post approximately 600mm (24") into the ground. Post must be plumb and level.

#### 2 Post

**For boards up to 2000mm wide.**

- Drill out 4 no partly drilled counter-sunk holes 6mm (15/64") as per drawing.

**Distance between posts (x on diagram)**

	Board Code	(x) Distance (mm)
<b>Single Bay</b>	P3A4	129
	PSN	372
	P6A4	549
	P6A4P	339
	P9A4	549
	PLN	600
	PL8A4	758
<b>2 Bay</b>	PL10A4	982
	PDN	982
	PD6A4	996
	PD6A4P	916
	PD9A4	996
	PDLN	1098
	PTN	1252
<b>3 Bay</b>	PT6A4P	1153

#### 3 Post

**For boards over 2000mm wide.**

- Drill out 6 no partly drilled counter-sunk holes 6mm. (15/64") as per drawing.

**Distance between posts (x on diagram)**


	Board Code	(x) Distance (mm)
<b>2 Bay</b>	PDL8A4	833 (x2)
	PDL10A4	1057 (x2)
<b>3 Bay</b>	PT6A4	1017 (x2)
	PT9A4	1017 (x2)

- Then Drill 3.5mm. (9/64") pilot holes in the post and fasten the board to the post using screws supplied.
- Concrete the post approximately 600mm (24") into the ground. Post must be plumb and level.


### Maintenance

Every year lubricate hinges and locks with grease.


Single Bay & 2 Bay




3 Bay




Board P3A4 only



88 x 88 post



88 x 88 post



88 x 88 post

### Damaged Items

In the unlikely event of damage occurring in transit, please advise us of this within **24 hours of receipt**, in order that we may claim against the carriers.